





Starting

: Parts Location

Code		See Page	Code		See Page	Code		See Page
B9	A	44 (*1)	E1	A	44 (*1)	E2	G	44 (*1)
		45 (*2)			52 (*4)			52 (*4)
		52 (*4)		B	45 (*2)		H	45 (*2)
		53 (*5)			53 (*5)			46 (*3)
B10	E	46 (*3)		C	45 (*2)			53 (*5)
		54 (*6)			53 (*5)			54 (*6)
B34		48 (LHD)		D	45 (*2)	H20		49 (LHD)
		56 (RHD)			53 (*5)			57 (RHD)
D37		44 (*1)		E	46 (*3)	H25		49 (LHD)
		45 (*2)			54 (*6)			57 (RHD)
		52 (*4)		F	46 (*3)	O1	C	48 (LHD)
		53 (*5)			54 (*6)			56 (RHD)

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
2	28	Engine Room R/B No.2 (Inside of Battery Room)
4	29	Instrument Panel R/B (Under the Glove Box)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	24	Engine Room Main Wire and Engine Room J/B No.1 (Engine Compartment Front)
1G		
5F	30	Instrument Panel Wire and Instrument Panel J/B (Left Side of Instrument Panel)
5G	30	Engine Room Main Wire and Instrument Panel J/B (Left Side of Instrument Panel)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BE1	60 (*1)	Engine Room Main Wire and Engine No.2 Wire (LH Side Battery Room)
	61 (*2)	
	62 (*3)	
	68 (*4)	
	69 (*5)	
	70 (*6)	
DB1	60 (*1)	Engine Wire and Engine Room Main Wire (Front Side of Engine Room R/B No.1)
	61 (*2)	
	68 (*4)	
	69 (*5)	
DB3	60 (*1)	Engine Wire and Engine Room Main Wire (Front Side of Engine Room R/B No.1)
	61 (*2)	
	68 (*4)	
	69 (*5)	
HB1	64 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Under the Instrument Panel J/B)
	72 (RHD)	
HB2	64 (LHD)	
	72 (RHD)	
OB1	65 (LHD)	Floor Wire and Engine Room Main Wire (RH Side of Instrument Panel R/B)
	73 (RHD)	Floor Wire and Engine Room Main Wire (Near the Stop Lamp SW)

* 1 : LHD 2TR-FE * 2 : LHD 2KD-FTV * 3 : LHD 5L-E * 4 : RHD 2TR-FE * 5 : RHD 2KD-FTV * 6 : RHD 5L-E * 7 : 2TR-FE
 * 8 : 2KD-FTV, 5L-E



: **Ground Points**

Code	See Page	Ground Points Location
B3	60 (*1)	Front Floor Panel Left
	61 (*2)	
	62 (*3)	
	68 (*4)	
	69 (*5)	
	70 (*6)	

* 1 : LHD 2TR-FE * 2 : LHD 2KD-FTV * 3 : LHD 5L-E * 4 : RHD 2TR-FE * 5 : RHD 2KD-FTV * 6 : RHD 5L-E * 7 : 2TR-FE
* 8 : 2KD-FTV, 5L-E