




# CIRCUITO DE ARRANQUE Y CARGA

Moror K4M T/A

L65  
02






## CIRCUITO DE ARRANQUE Y CARGA

Moror K4M T/A

L65  
03






# CIRCUITO DE ARRANQUE Y CARGA

BVA4/K4M743

L65  
02



3-15



## CIRCUITO DE ARRANQUE Y CARGA

L65  
03

Motor K4M/T/M

